



壁面サイン

壁面サイン 702 A仕様 / 702 C仕様 →P.108

姿図(S=1/25)




断面詳細図(S=1/4)




壁面サイン 7131 A仕様 / 7131 C仕様 →P.109

姿図(S=1/25)




断面詳細図(S=1/4)




突き出しピクトサイン 7D707 →P.110

姿図(S=1/20)




断面詳細図(S=1/4)




突き出しピクトサイン 7S707 →P.111

姿図(S=1/20)




断面詳細図(S=1/4)



吊り下げピクトサイン 7J707 →P.110

姿図(S=1/20)



断面詳細図(S=1/4)

